



Edition 19980122-19980131

Pos	Code	Description	Info
001	111AA05	RUBBER HOSE Ø30 Ø20	01/03/1996-
002	131AA23	RUBBER HOSE Ø35 Ø28	01/03/1996-
003	131AA12	RUBBER HOSE Ø17 Ø10 X H ² O	01/03/1996-
004	3170090	WASHER	01/03/1996-22/11/2010
005	137AA15	GASKET	01/03/1996-
006	107WR01	JUNCTION BOX	01/03/1996-
007	171WR01	JUNCTION BOX	01/03/1996-
008	35C3681	LH PANEL ASS.Y	22/01/1998-
009	30W3280	TRAY ASS.Y	01/03/1996-16/03/1999
010	30D4900	COOKING CHAMBER	01/03/1996-31/05/1998
011	35D8680	CHAMBER CONVEYOR	01/03/1996-31/05/1998
012	30G2910	OVEN COVER ASS. Y	01/03/1996-
013	30T5562	FRAME ASS. Y	01/03/1996-31/05/1998
014	30Z0491	WATER INLET PIPE ASS.Y	01/03/1996-31/05/1998
015	30Z0501	END PIPE, COMPLETE	01/03/1996-31/05/1998
016	30Z7691	STEAM DRAIN PIPE ASS.Y	01/03/1996-
017	33Q6100	LOWER DRAIN PIPE	01/03/1996-
018	36G6750	RING NUT	01/03/1996-
019	3140300	HOSE CLAMP	10/01/1997-
020	3140230	12/20 PIPE CLAMP	01/03/1996-
021	3140300	HOSE CLAMP	01/03/1996-
022	3140380	HOSE CLAMP	01/03/1996-
023	3150900	GASKET	01/03/1996-
024	3151440	WASHER	01/03/1996-13/10/1998
025	3151450	WASHER	01/03/1996-
026	3151490	BEARING	01/03/1996-
027	3190020	SCREW M6X10	01/03/1996-
028	3170110	ACCOMODATION Ø6	01/03/1996-
029	3201540	FUSE 5X20	01/03/1996-
031	32D0950	LIVE TERMINAL	01/03/1996-
032	32D0970	GROUND TERMINAL	01/03/1996-
033	32D0960	TERMINAL END COVER	01/03/1996-
034	32D0641	FUSE TERMINAL BOARD	01/03/1996-14/04/1998
035	31X0170	PIN FT Ø6	01/03/1996-
036	32M3811	FAN FL 280	01/03/1996-08/06/1998
037	32M3820	MOTOR	01/03/1996-
038	32W0210	OVEN LAMP 25 W	01/03/1996-
039	32W2561	LAMP HOLDER	01/03/1996-
040	32W3020	MICRO SWITCH	01/03/1996-13/11/1999
041	37M6210	GLASS	01/03/1996-03/08/2004
042	32X0120	GROMMET Ø 21	01/03/1996-
043	32X0130	GROMMET Ø29-Ø37	01/03/1996-
044	32Z0930	RELAY 0.9-1.5A	01/03/1996-07/04/1998
044	32Z6140	RELAY	01/03/1996-07/04/1998
045	32Z2081	RELAY 230V-50HZ	01/03/1996-
045	32Z2311	RELAY 220V-50/60HZ	01/03/1996-
045	32Z2531	RELAY 240V-50/60HZ	31/12/1997-07/04/1998
046	32Z5872	PRESSURESTAT	01/06/1997-29/09/2004
047	33D1641	SOLENOID VALVE 50/60HZ	01/03/1996-09/05/1999
048	33D1650	"PRES. REDUC. VAL. F-F Ø 1/2""	01/03/1996-
049	33D1680	MANOMETRE 0-40BAR M1/8	01/03/1996-

Pos	Code	Description	Info
050	33Q5410	VALVE CONNECTOR	01/03/1996-
051	33Q5420	"ELBOW FF 3/4""	01/03/1996-
052	33Q5450	DEPRES. CONNECTOR	01/03/1996-
053	30Z0480	WATER DIFFUSER	01/03/1996-
054	33Q5592	NOZZLE SUPPORT. ELBOW	01/03/1996-
055	33Q5641	ENTRY CONNECTOR H2O	01/03/1996-
056	33Q5690	BUSHING SUPPORT	01/03/1996-
057	33Q5980	SOUND REDUC. CONNECTOR	01/03/1996-
058	33T3720	NOZZLE	01/03/1996-
059	35C2820	INSULATION PANEL	01/03/1996-
060	35C5440	COVER INS. PANEL COVERING	01/03/1996-
061	35B4821	INSULATION PANEL COVER	01/03/1996-
062	35B5772	REAR PANEL	01/03/1996-
063	35C4520	RIGHT PANEL	01/03/1996-
064	3AQ0100	COMPON. PROTECTION	01/03/1996-
065	3033400	FILTER	01/03/1996-
066	35Q8200	PANEL BOARD	01/03/1996-02/12/1999
067	35Q2380	END RUN PROTECTION	01/03/1996-
069	35S5970	GUIDE CONTERWEIGHT	01/03/1996-31/12/1999
070	35S6082	FLAT BRACKET	21/05/1996-
071	35V8081	LAMPHOLDER SUPPORT	01/03/1996-
072	32D0260	LOCK NUT PG29	01/03/1996-
073	33Q5921	CONNECTOR	01/03/1996-
074	32D0651	TERMINAL	01/03/1996-23/01/2002
075	35V5810	OMEGA BRACKET	01/03/1996-
076	35X0540	DRAIN PIPE	01/03/1996-
077	35X0550	PIPE	01/03/1996-
078	35Z2620	PIPE	01/03/1996-31/01/1998
079	36A3390	DRAIN TRAP	01/03/1996-
080	36A3400	DRAIN	01/03/1996-
081	36D5730	STAINLESS STEEL	01/03/1996-16/02/1999
082	36D7121	FAN PROTECTION	01/03/1996-31/05/1998
083	36D7140	BUSHING	01/03/1996-
084	36G5320	SPRING	01/03/1996-
086	36G5380	COUNTERWEIGHT	01/03/1996-30/12/2005
087	36G6740	COUNTERWEIGHT	01/03/1996-
088	36G6040	END RUN PIN	01/03/1996-19/01/2000
089	32X0140	GROMMET Ø13,5-Ø25	01/03/1996-
090	36Q1171	LOCKNUT M16X1.5	01/03/1996-
091	36C3070	PIN	01/03/1996-17/11/2004
092	37Q3011	GASKET	01/03/1996-
093	3151730	GASKET	01/03/1996-
094	37Q7840	GASKET	01/03/1996-
095	3AA0981	CONTROL BOARD ASS.Y	01/03/1996-
096	35V5212	LH FOOT HOLDER	01/03/1996-
097	30T6590	SMALL END SUPPORT	01/03/1996-
098	6300416	OVEN DOOR ASS. Y	01/03/1996-
099	35V9050	HANDLE SHAPED BAR	01/03/1996-
100	30G0811	DOOR ASS. Y	01/03/1996-
101	35G0350	OVEN COUNTER DOOR	01/03/1996-
102	33Q1150	DISTANCIAL BUSHING	01/03/1996-21/06/1998

Pos	Code	Description	Info
103	35V4410	PLATE	01/03/1996-
104	36D8360	MICROSWITCH ROD	01/03/1996-
105	36M4122	DOOR HINGE	01/03/1996-
106	35Q2360	SUPP. END RUN PROTECTION	01/03/1996-
107	37M0240	CHAMBER GLASS ASS. Y	01/03/1996-
108	37Q0951	DOOR GASKET	01/03/1996-07/03/1999
109	37Q2981	GASKET	01/03/1996-24/03/1999
110	6300420	LOCK ASS. Y	01/03/1996-
111	35V3290	SPILLAGE TRAY SUPPORT	01/03/1996-
112	35V8072	LAMP HOLDER BOX	01/03/1996-
113	35V9030	CHAMBER GLASS	01/03/1996-
114	35X2900	SUPP. DOOR DRAIN PIPE	01/03/1996-
115	36C0970	SPACER	01/03/1996-
116	3FL1256	WHEEL ASS. Y	01/03/1996-31/05/1998
117	37M4040	RATING INSERT	01/03/1996-04/05/1999
118	36M0820	LOCK HOUSING	01/03/1996-
119	3150790	THERMOSTAT PROTECT.	01/03/1996-
120	3170290	KNOB SPRING	01/03/1996-
121	32W2941	COMMUTATOR	01/03/1996-
122	6300446	PIN Ø 10 ASS. Y	01/03/1996-31/05/1998
123	32Z5511	SAFETY THERMOSTAT	01/03/1996-28/10/2008
124	32Z5820	THERMOSTAT 50-250° C	01/03/1996-
125	37M5641	PLASTIC COATED PANEL	01/03/1996-
126	32Z6330	TIMER 0-120' 220/240V-50HZ	01/03/1996-
126	32Z6440	TIMER 0-120 60HZ	01/03/1996-
127	32Z6191	TEMP.PROBE PT100	01/03/1996-
128	32Z5860	BUZZER 50"	01/03/1996-
129	32Z5880	THERMOSTAT 30-90°C	01/03/1996-
130	36D7060	PIN	01/03/1996-31/12/2003
131	36M4560	ELECTRIC CONTROL	01/03/1996-
132	33Q3210	KNOB PLUG	01/03/1996-
133	33Q5381	RING SUPPORT	01/03/1996-
134	33Q5390	"RING 3/4""	01/03/1996-
135	33Q5620	CONNECT M16X1.5 M10	01/03/1996-13/11/1999
136	33Q5610	RING M16X1.5	01/03/1996-
137	33Q5630	CONNECT MF 3/8"- M16	01/03/1996-
138	33Q5650	SOCKET F3/4 M1/2 Ø30X25	01/03/1996-
139	35S6361	L" SHAPED BAR	29/04/1996-
140	36E2530	PLASTIC INSERT LOCK	01/03/1996-
143	33Q5442	CONNECTOR Ø 0.5	01/03/1996-
144	3190040	SCREW M6X20	01/03/1996-
145	36M1570	LOCK SPACER	01/03/1996-
146	32Z6210	P.C.B.	01/03/1996-15/02/2000
147	36Q0190	Cap Ø20	01/03/1996-
148	36Q0550	LOCK NUT M12X1.5	01/03/1996-
149	32D0210	FAIRLED	01/03/1996-
150	32G1691	HEATING ELEMENT 8,7KW 230V - 9.5KW 240V	01/03/1996-
151	35Q1450	HEAT ELEMENT BRACKET	01/03/1996-
152	36M3180	HINGE ASS. Y	01/06/1997-04/05/1999
153	35S8850	"L" BRACKET	01/03/1996-
154	36D8492	FEELER SUPPORT	01/03/1996-

Pos	Code	Description	Info
155	37Q3220	GASKET	01/03/1996-
156	35Q6360	THERMORES. PROTECTION	01/03/1996-
157	33Q6091	H2O FILTER 3/4"	01/03/1996-
158	36G7140	SPRING	01/03/1996-
159	32Q2020	EL. CABLES FCVE	01/03/1996-14/04/1998
160	32Q3680	CABLES FCV61E	01/03/1996-
161	36Q1550	CAP Ø11	22/01/1998-
164	35Y0550	LEFT TRAY GUIDE	06/01/1998-
165	30T3350	RH FRAME ASS. Y	06/01/1998-
167	32Z3512	RELAY 220/230V-55A- 50/60Hz	01/03/1996-31/12/2007



PLATON SERVICE

8 (800) 500-34-41

www.platonservice.com