



Spare Parts Catalogue
Catalogue de pièces de rechange




IC4 4819-4832


Ironer
Sécheuse repasseuse



Issue	Month	Year
02	05	05





610776



610777


Issue	Month	Year
03	05	06






610785


Issue	Month	Year
02	10	06





610783

Issue	Month	Year
05	05	06











610765

Issue	Month	Year
01	06	04





610766

Issue	Month	Year
01	06	04




610780

Issue	Month	Year
02	12	05





610768

Issue	Month	Year
01	06	04






Issue	Month	Year
01	10	06






Issue	Month	Year
01	10	06





610781


Issue	Month	Year
01	06	04





①
















①



⑥



Issue	Month	Year
01	05	05