


Spare Parts Catalogue  
Catalogue de pièces de rechange

---




IC4 4819-4832

---


Ironer  
Sécheuse repasseuse

---




610775

Issue	Month	Year
02	05	05




610776




610777

Issue	Month	Year
03	05	06




610778


Issue	Month	Year
03	05	06




610785


Issue	Month	Year
02	10	06
















610765

Issue	Month	Year
01	06	04





610766

Issue	Month	Year
01	06	04




610780

Issue	Month	Year
02	12	05




610768


Issue	Month	Year
01	06	04






Issue	Month	Year
01	10	06








Issue	Month	Year
01	10	06





610781


Issue	Month	Year
01	06	04





①

















①



⑥

