



Spare Parts Catalogue
Catalogue de pièces de rechange




IC4 4819-4832

Ironer
Sécheuse repasseuse




610775

Issue	Month	Year
02	05	05





610776



610777


Issue	Month	Year
03	05	06








610785


Issue	Month	Year
02	10	06













610765


Issue	Month	Year
01	06	04






610780

Issue	Month	Year
02	12	05




610768




Issue	Month	Year
01	06	04



611027


Issue	Month	Year
01	10	06






610781


Issue	Month	Year
01	06	04





①





Issue	Month	Year
02	12	04














Issue	Month	Year
01	05	05