

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+ 1	SL0134		Pusher
2	SL0136		Hopper
3	SL0140		Shaft
4	SL0139	ø25xø40x7	Oil seal
5	SL0131	6203 2RS	Bearing
+ 6	SL0138		Knob
+ 7	SL2917		Tap
8	SL3980		Sleeve
9	SL0132	ø40	Seeger
10	SL0130		Gear
11	SA3710	Assembly	Sleeve
12	SL0125		Gear
13	SL0124		Shaft
14	SA1014	400V/3Ph/50Hz	Stator
14	SA1015	230V/1Ph/50Hz	Stator
15	SL0128		Gear
16	SL0127	ø17xø40x7	Oil seal
17	SA7300	400V/3Ph/50Hz	Rotor
17	SA7400	230V/1Ph/50Hz	Rotor
18	SL0186		Calotte
19	SL2833		Cover
20	SL1841	3Ph+Gnd	Electric cable
20	SL1671	1Ph+N+Gnd	Electric cable
21	SL1668	PG11	Cable clamp
22	SL0142	Stainless-steel	Sleeve
22	SL3078	Food stuff treated steel	Sleeve
+ 23	SA5300	Stainless-steel	Screw shaft
23	SA5350	Food stuff treated cast-iron	Screw shaft
24	SL2521		Pivot
+ 25	////////		Cutter
+ 26	////////		Plate
27	SL0171	Stainless-steel	Handwheel

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
27	SL3327R0	Aluminium	Handwheel
28	SL0180		Container
29	SL2566		Base
+ 30	SL0891	Start-stop	Push button
31	SL0177	16µF	Condenser
32	SL0176		Bracket
+ 33	SL0883		Electronic card
34	SL0235		Foot
35	SL2651		Bottom
36	SL0054		Switch

