



TR12TS

Pos. Ref.	Codice Code	Caratteristiche Features	Descrizione Description	
1	SL2527		Albero	Shaft
2	SL2917	●	Tappo	Tap
3	SL2526		Calotta	Calotte
4	SL2591	∅25x∅47x8	Paraolio	Oil seal
5	SL2592	6205 2RS	Cuscinetto	Bearing
6	SL0082	∅47	Seeger	Seeger
7	SL2593	∅20x∅47x8	Paraolio	Oil seal
8	SL0130		Ingranaggio	Gear
9	SA2500	Assembly	Calotta	Calotte
10	SL2924	●	Pomello	Knob
11	SL0125		Ingranaggio	Gear
12	SL2589		Albero	Shaft
13	SA1014	400V/3Ph/50Hz	Statore	Stator
13	SA1015	230V/1Ph/50Hz	Statore	Stator
14	SL0128		Ingranaggio	Gear
15	SL0127	∅17x∅40x8	Paraolio	Oil seal
16	SL0131	6204 2RS	Cuscinetto	Bearing
17	SA7300	400V/3Ph/50Hz	Rotore	Rotor
17	SA7400	230V/1Ph/50Hz	Rotore	Rotor
18	SL1841	3Ph+Gnd	Cavo elettrico	Electric cable
18	SL1671	1Ph+N+Gnd	Cavo elettrico	Electric cable
19	SL0186		Calotta	Calotte
20	SL2833		Coperchio	Cover
21	SL1668	PG11	Pressacavo	Cable clamp
22	SL0134	●	Pestello	Pusher
23	SL0136		Tramoggia	Hopper
24	SL2566		Base	Base
25	SL2416	Stainless-steel	Bocchettone	Sleeve
25	SL2553R0	Food stuff treated cast-iron	Bocchettone	Sleeve
25	SL2546	Unger	Bocchettone	Sleeve
26	SA5300	● Stainless-steel	Elica	Screw shaft
26	SA5350	Food stuff treated cast-iron	Elica	Screw shaft
26	SA2600	Unger	Elica	Screw shaft
27	SL2521		Perno	Pivot
27	SL2561	Unger	Perno	Pivot
28	////////	●	Coltello	Cutter
29	////////	●	Piastra	Plate
30	SL0171	Stainless-steel	Volantino	Handwheel
30	SL3327R0	Aluminium	Volantino	Handwheel
31	SL0180		Recipiente	Container
32	SL0891	● Start-stop	Pulsante	Push button
33	SL0883	●	Scheda elettronica	Electronic card
34	SL0177	16µF	Condensatore	Condenser
35	SL0176		Staffa	Bracket
36	SL2651		Fondo	Bottom
37	SL0235		Piedino	Foot
38	SL0054		Interruttore	Switch

(*) : fuori produzione / out of production

● : ricambio consigliato / spare part suggested