


Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
+ 1	SL0134		Pusher
2	SL0135		Hopper
3	SL1841	3Ph+Gnd	Electric cable
3	SL1671	1Ph+N+Gnd	Electric cable
4	SL3104		Label
5	SL1668	PG11	Cable clamp
6	SL3041		Housing
7	SL3102		Pivot
+ 8	SL0891	Start-stop	Push button
9	SL3986	Stainless-steel	Sleeve
9	SL2523R0	Food stuff treated cast-iron (without CE norms)	Sleeve
9	SL3987	Unger	Sleeve
+ 10	SL2924		Knob
+ 11	SA5500	Stainless-steel	Screw shaft
11	SA5400	Food stuff treated cast-iron (without CE norms)	Screw shaft
11	SA5700	Unger	Screw shaft
12	SL0823		Pivot
12	SL0824	Unger	Pivot
+ 13	////////		Cutter
+ 14	////////		Plate
15	SL0197	Stainless-steel	Handwheel
15	SL3328R0	Aluminium (without CE norms)	Handwheel
16	SL0130		Gear
17	SL2593	ø20xø47x8	Oil seal
18	SL3125	6204 2RS	Bearing
19	SL0082	ø47	Seeger
20	SL2591	ø25xø47x8	Oil seal
+ 21	SL2709		Tap
22	SL3112		Calotte
23	SL2528		Shaft
24	SA1320	Assembly	Calotte
25	SL0125		Gear

+ : ricambio consigliato / spare part suggested

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
26	SL2589		Shaft
27	SA1016	400V/3Ph/50Hz	Stator
27	SA1017	230V/1Ph/50Hz	Stator
28	SL0128		Gear
29	SL0127	∅17x∅40x8	Oil seal
30	SL0131	6203 2RS	Bearing
31	SL2600	400V/3Ph/50Hz	Rotor
31	SL2601	230V/1Ph/50Hz	Rotor
32	SL0186		Calotte
33	SL3082		Spacer
34	SL0176		Bracket
35	SL0931	20µF	Condenser
 36	SL0883		Electronic card
37	SL3020		Spacer
38	SL3049		Bottom
39	3178340		Foot
40	SL0054		Switch

