

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description	
1	SL3274		Washer	
2	SA1114		Lever press	
3	SL3177		Support	
4	SL1497		Washer	
5	SL3176		Pivot	
+	6	SL0885	Microswitch	
7	SL3180		Cover	
+	8	SL0841	Pusher	
9	SL0106		Grip	
10	SL3424	TV2000R-3000 (Stainless steel)	Casing	
10	SL3464	TV2500 (Plastic)	Casing	
11	SL3258	TV2000R	Knob	
12	SL3425	TV2000R	Magnet	
+	13	SL1838	TV2000R-3000	Knob
13	SL3626	TV2500	Knob	
14	SL1074	M5x25 A2 (TV2000R-3000)	Grub screw	
14	SL3625	M5x35 A2 (TV2500)	Grub screw	
+	15	SL0843	Low	Ejector disk
+	15	SA2700	High	Ejector disk
16	SL1360R0		Shaft	
17	SL1373		Washer	
18	SL1376		Shim	
19	SL1380	ø25xø40x6	Oil seal	
20	SL0131	6203 2RS	Bearing	
21	SL1381		Shim	
22	SL1388		Ring	
23	SL3174		Body	
+	24	SL0891	Start-stop (TV2000R-3000)	Push button
24	SA1048	Assembly (TV2500)	Electronic card	
25	32W3240	TV2000R	Microswitch	
26	SL1668	PG11	Cable clamp	
27	SL3540	TV2000R	Housing	

Rif./Ref.	Codice/Code	Sigla /Features	Descrizione/Description
27	SL3171	TV3000	Housing
27	SL3469	TV2500	Housing
+ 28	SA1240	400V/3Ph/50-60Hz (TV2000R-3000)	Electric installation
+ 28	SA1250	230V/1Ph/50-60Hz (TV2000R-3000)	Electric installation
29	SL3184		Bracket
30	36G0030		Pulley
31	SL1467		Flange
+ 32	SL1473	Poly V-762 j10	Belt
33	SL1471	400V/3Ph/50Hz	Motor
33	SL1470	230V/1Ph/50Hz	Motor
34	36G6600		Pulley
35	SL3179		Bottom
+ 36	SL0235		Foot
37	SL1391	ø5x22 A2	Pin
38	SL3575R0		Washer
39	SL2549		Tap
40	SL3867		Spacer



PLATON SERVICE  
 8 (800) 500-34-47  
 www.platonservice.com

