



**Lavastoviglie
Lave-vaisselle
Dishwashers
Geschirrspüler
Lavavajillas**

DSP5

**Ed.
09/2007**


Rev. C

DSP5



**PARTI DI RICAMBIO
PIECES DETACHEES
SPARE PARTS
ERSATZTEILE
REPUESTOS**





0800186

0800066

0800163

0400152
(option)

0200118

0200097

0200117

0200069

0201919

0200164

0303042

0200056

0200080

0301204

0200069

0800626

0200116

0200099

0200098

0300303

0406250

0201891

0202113

0500505

0800053

0800061

0800009

0500500

0800052

0202101

0200025

0200180

0200113

0200173

0200114

0800185

0800107

0800093

0200403


0221302


0200298

0200112

0200069

0200232





QUADRO ELETTRICO - TABLEAU ELECTRIQUE
 CONTROL BOX - SCHALT-TAFEL - CAJA ELÉCTRICA

MOD.
DSP5

TAV.
3 C

TAV. 3 DI 7
 ED. 09/2007

