






- 0 530 090: 4/6rpm; 90/120W
- 0 530 091: 6/9rpm; 90/120W
- 0 530 101: 6/9rpm; 120/170W
- 0 530 102: 12/18rpm; 120/170W



PLATON SERVICE

8 (800) 500-34-41


www.platonservice.com

8 132 013

8 132 239

8 132 014





PLATON SERVICE  
 8 (800) 500-34-4  
 www.platonservice.com

# Basket transport machine




# K 200 E





## Spare Parts List



Ident.-No. 9 518 623  
1998/99












8132179	8132181
Arbeitsrichtung L-R	Arbeitsrichtung R-L
Working Direction L-R	Working Direction R-L
Sens de Travail G-D	Sens de Travail D-G



**Pos. 10**





8 101 276



0 620 351



PLATON SERVICE

www.platon.com 47

8 (800) 100 100




**PLATON SERVICE**

8 (800) 500-34-47

[www.platonservice.com](http://www.platonservice.com)

8130830






0465007


0621003

PLATON SERVICE

500-34-41

www.platonservice.com











Pos. 1




PLATON SERVICE

8 (800) 50...-47  
www.platons.com




8132617  
Arbeitsrichtung L-R  
Working Direction L-R  
Sens De Travail G-D

0620422



8132621  
Arbeitsrichtung L-R  
Working Direction L-R  
Sens de Travail G-D

0620422



PLATON SERVICE  
8 (800) 500-34-47  
www.platonservice.com