



Artic./Item	Descrizione/Description	Modello/Model
313073	GRIGLIA GAS A PIETRA LAVICA GAS LAVASTONE GRILL	GR8FG9

Cons./Recom.	Pos./Posit.	Ricambio/Replacement		
	01361000	RC01361000	CAMINO H25 L9	FLUE H25 L9
	01784000	RC01784000	MANIGLIA VANO PROFI3520	HANDLE
	02078000	RC02078000	SOTTOMANOPOLA GAS NEUTRO NERO	BLACK UNDERKNOB
	02111000	RC02111000	MANOPOLA CUOCIPASTA/GRIGLIA P.L.GAS NERA	BLACK KNOB
	K2004912	RCK2004912	BUSSOLA PER PERNO PORTA D.7X10	BUSH FOR DOOR PIN D.7X10
	K2010924	RCK2010924	BRUCIATORE AISI 304 GRIGLIA S 900	BURNER GR_G9
	K2011301	RCK2011301	LEVA DX MOVIMENTO GRIGLIA ASS.TA	RIGHT LEVER FOR GRID MOVEMENT
	K2011302	RCK2011302	LEVA SX MOVIMENTO GRIGLIA ASS.TA	LEFT LEVER FOR GRID MOVEMENT
	K2011369	RCK2011369	TELAIO PORTALAVA 538X360MM ASS.TO	FRAME FOR LAVA KOLDER
	K2011372	RCK2011372	GRIGLIA 1/2 CARNE PER GR8FG9	GRID FOR MEAT GR8FG9 (1/2 MODULE)
	K2011375	RCK2011375	CORNICE SOLL.GRIGLIA ASS.TA	FRAME GRID GR_G9
	K5900149	RCK5900149	MANIGLIA NERA COD. 19701 60X20M8	BLACK HANDLE
	K5900350	RCK5900350	CHIUSURA MAGNETICA D.30 C/RONDELLA	MAGNET
	K6010047	RCK6010047	ACCENSIONE PIEZOELETTRICA PZ10023	PIEZOELECTRIC IGNITION PZ10023
	K6010055	RCK6010055	TERMOCOPPIA PER FRIGITRICE	THERMOCOUPLE FOR REFRIGERATOR
	K6010087	RCK6010087	CANDELETTA DI ACCENSIONE	SPARK PLUG
	K6050610	RCK6050610	CAVO PER ACCENSIONE CA-3934/08 700	IGNITION CABLE
	K7060012	RCK7060012	RUBINETTO GAS PER CUOCIPASTA	GAS TAP FOR PASTA COOKER
	K7090028	RCK7090028	BRUCIATORE PILOTA 1 FIAM.0140015	PILOT BURNER
	02081000	RC02081000	SOTTOMANOPOLA GAS NEUTRO GRIGIO	GREY UNDERKNOB
	02112000	RC02112000	MANOPOLA CUOCIPASTA/GRIG.P.L.GAS GRIGIA	GREY KNOB