


6.4 Spare Parts

Defect parts are to be replaced only by original spare parts of the company UBERT GASTROTECHNIK GMBH; the replacement is to be carried out only by their service personal or by your authorized Service companies. Only these two companies are allowed to carry out service work and replacement of defect parts. If you do not observe this note or in case of manipulation of a third party any claims for guarantee will become invalid! Also all certifications (CE, UL, NSF and the like) become invalid!



6.4.1 Explosion Diagram

DHT and DHTSS-Series



6.4.2 Spare Parts List

DHT31 and DHT31SS

| Pos. | Description | Part No. | Amount |
|------|----------------------------|----------|--------|
| 1 | front glass assy | 121783 | 1 |
| | front glass top | 421022 | 1 |
| 2 | reflector | 121780 | 1 |
| 3 | lamp socket | 340412 | 6 |
| 4 | halogen lamp 150W | 340625 | 3 |
| 5 | intermediate rail | 121740 | 2 |
| 6 | heating element 1150W | 343150 | 3 |
| 7 | crumb drawer | 121798 | 2 |
| 8 | pressure lift | 460101 | 2 |
| 9 | lighting screen holder | 460002 | 2 |
| 10 | side glass | 421010 | 2 |
| 11 | fan | 344104 | 1 |
| 12 | terminal block 2-pole | 333302 | 2 |
| 13 | terminal block 4-pole | 333323 | 6 |
| 14 | end cap for terminal block | 333324 | 1 |
| 15 | sliding glass right | 121786 | 1 |
| 16 | sliding glass left | 121785 | 1 |
| 17 | water drawer | 121799 | 2 |
| 18 | thermometer 0-120°C | 342907 | 1 |
| 19 | switch | 341108 | 2 |
| 20 | knob | 361311 | 1 |
| 21 | display UBERT | 360146 | 1 |
| 22 | thermostat | 342210 | 1 |
| 23 | contactor | 342409 | 1 |
| 24 | track for terminal blocks | 121750 | 1 |
| 25 | strain relief counter nut | 338111 | 1 |
| 26 | strain relief PG 16 | 338109 | 1 |
| | guide bar | 121777 | 1 |
| | guide bar bottom | 121778 | 1 |

DHT41 and DHT41SS

| Pos. | Description | Part No. | Amount |
|------|----------------------------|----------|--------|
| 1 | front glass assy | 121549 | 1 |
| | front glass top | 421036 | 1 |
| 2 | reflector | 121780 | 1 |
| 3 | lamp socket | 340412 | 8 |
| 4 | halogen lamp 150W | 340625 | 4 |
| 5 | intermediate rail | 121740 | 3 |
| | heating element 1000W | 343115 | 2 |
| 6 | heating element 1150W | 343150 | 4 |
| 7 | crumb drawer small | 121885 | 2 |
| 8 | pressure lift | 460001 | 2 |
| 9 | lighting screen holder | 460002 | 2 |
| 10 | side glass | 421010 | 2 |
| 11 | fan | 344104 | 1 |
| 12 | terminal block 2-pole | 333302 | 3 |
| 13 | terminal block 4-pole | 333323 | 6 |
| 14 | end cap for terminal block | 333324 | 1 |
| 15 | sliding glass right | 121548 | 1 |
| 16 | sliding glass left | 121547 | 1 |
| 17 | water drawer | 121528 | 2 |
| 18 | thermometer 0-120°C | 342907 | 1 |
| 19 | switch | 341108 | 2 |
| 20 | knob | 361311 | 1 |
| 21 | display UBERT | 360146 | 1 |
| 22 | thermostat 30-110°C | 342218 | 1 |
| 23 | contactor | 342409 | 1 |
| 24 | track for terminal blocks | 121750 | 1 |
| 25 | strain relief counter nut | 338111 | 1 |
| 26 | strain relief PG 16 | 338109 | 1 |
| | guide bar | 121777 | 1 |
| | guide bar bottom | 121778 | 1 |

DHT51 and DHT51SS

| Pos. | Description | Part No. | Amount |
|------|----------------------------|----------|--------|
| 1 | front glass assy | 121784 | 1 |
| | front glass top | 421025 | 1 |
| 2 | reflector | 121751 | 1 |
| 3 | lamp socket | 340412 | 10 |
| 4 | halogen lamp 150W | 340625 | 5 |
| 5 | intermediate rail | 121740 | 4 |
| 6 | heating element 1000W | 343115 | 2 |
| 7 | heating element 1150W | 343150 | 5 |
| 8 | crumb drawer small | 121885 | 2 |
| 9 | crumb drawer big | 121886 | 1 |
| 10 | pressure lift | 460001 | 2 |
| 11 | lighting screen holder | 460002 | 2 |
| 12 | side glass | 421010 | 2 |
| 13 | fan | 344104 | 2 |
| 14 | terminal block 2-pole | 333302 | 3 |
| 15 | terminal block 4-pole | 333323 | 6 |
| 16 | end cap for terminal block | 333324 | 1 |
| 17 | sliding glass right | 121788 | 1 |
| 18 | sliding glass left | 121787 | 1 |
| 19 | water drawer | 121887 | 2 |
| 20 | thermometer 0-120°C | 342907 | 1 |
| 21 | switch | 341108 | 2 |
| 22 | knob | 361311 | 1 |
| 23 | display UBERT | 360146 | 1 |
| 24 | thermostat 30-110°C | 342218 | 1 |
| 25 | contactor | 342409 | 1 |
| 26 | track for terminal blocks | 121750 | 1 |
| 27 | strain relief counter nut | 338111 | 1 |
| 28 | strain relief PG 16 | 338109 | 1 |
| | guide bar | 121746 | 1 |
| | guide bar bottom | 121748 | 1 |

DHT71 and DHT71SS

| Pos. | Description | Part No. | Amount |
|------|----------------------------|----------|--------|
| 1 | front glass assy | 121986 | 2 |
| | front glass top | 421046 | 2 |
| 2 | reflector | 121751 | 1 |
| 3 | lamp socket | 340412 | 14 |
| 4 | halogen lamp 150W | 340625 | 7 |
| 5 | intermediate rail | 121740 | 6 |
| 6 | heating element 1000W | 343115 | 2 |
| 7 | heating element 1150W | 343150 | 7 |
| 8 | crumb drawer small | 121885 | 2 |
| 9 | crumb drawer big | 121886 | 2 |
| 10 | pressure lift | 460207 | 8 |
| 12 | side glass | 421047 | 2 |
| 13 | fan | 344104 | 3 |
| 14 | terminal block 2-pole | 333302 | 7 |
| 15 | terminal block 4-pole | 333323 | 6 |
| 16 | end cap for terminal block | 333324 | 1 |
| 17 | sliding glass right | 121992 | 2 |
| 18 | sliding glass left | 121990 | 2 |
| 19 | water drawer | 121983 | 3 |
| 20 | thermometer 0-120°C | 342907 | 1 |
| 21 | switch | 341108 | 2 |
| 22 | knob | 361311 | 1 |
| 23 | display UBERT | 360146 | 1 |
| 24 | thermostat 30-110°C | 342218 | 1 |
| 25 | contactor | 342409 | 1 |
| 26 | track for terminal blocks | 121750 | 1 |
| 27 | strain relief counter nut | 338111 | 1 |
| 28 | strain relief PG 16 | 338109 | 1 |
| | guide bar | 121988 | 2 |
| | guide bar bottom | 121989 | 2 |